

## 3000VA pure sine wave UPS, LCD display, USB, black

EG-UPS-PS3000-01

### ULTIMATE DEFENCE

- Pure sine wave output
- Provide backup power Prevents data loss
- Protects your sensitive and valuable equipment
- Perfect support for solar panel installations and other sensitive equipment that requires pure sinewave input
- Compact and reliable ideal for home and small office use



### Karakteristike

- Uninterruptable power supply with pure sine wave output
- USB interface
- Automatic AC voltage regulation (AVR)
- Intelligent overload and short-circuit protection
- Audible and visual alarms
- LCD display and LED status indication
- Internal battery with overcharge and over-discharge protection

### Pakovanje i slike

|                                |                |
|--------------------------------|----------------|
| Q'ty in crtn, pcs              | 1              |
| Crtn volume, CUM               | 0.09792        |
| Crtn weight, kgs               | 32.15          |
| Individual package size LxWxH: | 592x462x320 mm |
| Carton size LxWxH:             | 600x340x480 mm |
| Country of origin              | CN             |
| Barcode                        | 8716309087377  |
| Customs code                   | 8504408590     |

### Package contents

UPS  
Power input cord  
Power IEC output cord x 2 pcs

### Sertifikati



### Specifikacije

Type: line interactive

Waveform: sine, 5% distortion at linear load, PF > 0.8

Input: AC 220V±25%, 50Hz/60Hz ±10%

Output: AC 220V±12%, 50Hz/60Hz ±1% (AC 220V±5% at inverter mode)

Switching time: up to 10 ms typically

Backup time: 10...30 mins (depends on the load)

Battery: 151 x 65 x 94 mm, sealed lead-acid 12V/9Ah, F2 terminals x 4 pcs

Charge time: up to 12 hours

Sockets: C14 input, 4 outputs x C13; USB-BF connector

Operating conditions: 0°C~40°C, at humidity 10~90%RH non condensing

Power: 3000VA (2400 W)

Charging current: up to 1.7 A

Noise: < 50 dB at 1 m distance

Dimensions: 467 x 336 x 190 mm

Product weight: 28.1 kg

Fuse: 15A

"Cold-start" function

### Sistemske zahteve

In order to work correctly, the connected load should be at least 5% of the maximum capacity of the UPS. For example, a 700 W UPS needs at least a connected load of 35 W to work.